



- 1) SCREW THE ADJUSTABLE FOOT INTO THE BASE OF THE SHELF POSTS. FIT THE PVC CAP TO THE FRONT OF THE SHELF POST.
- 2) STARTING WITH THE LEFT HAND POST, STAND IT UP AND FIX THE TOP AND BOTTOM BRACES USING THE PRE DRILLED LOCATING HOLES AND SUPPLIED FASTENERS. BE SURE TO USE THE CORRECT BRACES AS THE BRACES FOR END BAYS VARY FROM OTHER BAYS. THEY WILL HAVE ONE LEG LONGER THEN THE OTHER WHERE THE LOCATING HOLES ARE POSITIONED. THE FLAT SIDE OF THE BRACES MUST FACE THE REAR OF THE SHELVING SYSTEM. **THIS IS IMPORTANT FOR STABILITY**
- 3) FIX THE SECOND POST TO THE BRACES TO MAKE THE FIRST BAY.
- 4) USE A LEVEL TO CHECK THE ANGLE OF THE POSTS AND ADJUST IF REQUIRED. MAKE SURE ALL FASTENERS ARE FIXED CORRECTLY BEFORE PROCEEDING.
- 5) FROM THE FRONT OF THE BAY FIX SHELF SUPPORT BRACKETS TO THE NUMBERED SLOTS ON THE POSTS WHERE REQUIRED AND PUT SHELVES IN. IT IS RECOMMENDED THAT AT LEAST A TOP AND BOTTOM SHELF IS FITTED BEFORE PROCEEDING.
- 6) REPEAT STEPS 1 TO 5 FOR EACH BAY OF THE INSTALLATION.

Assembly Instructions for Maslen Canterlver Shelving System